

ment create a relaxing, healthful environoffice area or anywhere you want to be used in a bedroom, living room, air, providing immediate healthful benefits while helping to ionize the air. It can they are immediately dispersed into the mist. When essential oils are added, water inside the unit into an ultra fine ultrasonic technology that vibrates The Leah Diffuser uses high frequency



fill

0

cover and the vapor Remove the glass vase insert.

to the max fill line.

regular tap water up Using a cup, fill with

to wall outlet. Plug the cable into the unit first then connect

> your essential oil. Add 5 to 10 drops of

DO NOT FILL BASE UNDER RUNNING WATER. DO NOT ALLOW WATER TO ENTER THE AIR VENT. DO NOT FILL ABOVE MAX LINE.



check for alignment. Replace vapor insert,

vase over the base. Then, place the glass



begin. Press the power icon to

operation. 1st press for continuous

diffusing. 2nd press to turn off

OPERATION/CLEANING 6 CLEANIN





To control lights press the light icon.

Using a cotton swab

with warm water, gently clean the mist

disc and sensor located at the inside

1st press to turn on warm white light.

2nd press for color rotating lights.

bottom of the base.

3rd press to select displayed color.

4th press to turn lights off.

Cleaning:

- Rinse with warm water and clean as follows:
 Wine with path damp cleate to clean
- i. Wipe with soft damp cloth to clean.ii. Wipe with soft cloth and rubbing alcohol when needed to break up excessive oil residue.
- Use a cotton swab and water or rubbing alcohol to clean the ceramic disc inside the base.
 *See diagram to the left.
- We recommend cleaning the unit every time you change oils or every 2 uses.
- Do not use detergents or abrasive agents to clean the diffuser unit.

Do not return this diffuser to the retailer. Please contact the manufacturer's customer service for assistance. 1-888-548-0040

SYMPTOM	CAUSE	SOLUTION
No Mist	Using incorrect water, distilled or purified Unit is out of water	Use Tap Water (without filte Add additional water
No Mist or Little Mist	Unit needs to be cleaned. Oils are clinging to ceramic disc or sensor	Clean unit as advised in instructions with clean water & clean ceramic disc/senso with brush or swab.
	Water level is higher than max level line	Clean unit and add water 1/2 way to fill line and additional water after gettii mist.
	Nozzle or cover are not assembled correctly	Make sure the cover is aligned properly.
Blinking Lights	Water level indicator is dirty	Clean unit as advised. Pay particular attention to swat the sensor/disc inside the bottom of unit.
Unit will not stop running even though empty	Water level indicator is dirty	Clean unit as advised. Pay particular attention to swatch the sensor/disc inside the bottom of unit.
No misting and unit is spraying	Water is too cold	Change to warmer water.
CAUTION: Kee	CAUTION: Keep away from children and pets. Do not use on wooden or nainted surfaces that can be damaged by essential oil. Keep the	ot use on woode

CAUTION: Keep away from children and pets. Do not use on wooden or painted surfaces that can be damaged by essential oil. Keep the unit upright at all times. Do not tilt unit at any time as water may spill and damage furnishings and fabrics.

: F

DO NOT Please r Manufa Use of th	DO NOT USE DISTILLED WATER Please read the instructions carefully before using. Manufacturer accepts no liability for damage caused by incorrect use of the Essential OII diffuser.
Mo Mo	Warning and cautions Not allowed action
	1. Shut off and unplug the power before cleaning
	2. Clean the unit by rinsing the water tank and wiping it dry with a clean cloth
0	3. Do not use detergents, solvents or abrasive agents to clean the diffuser unit
	4. Clean the unit when changing to a different oil
	5. Use the original adapter provided by the manufacturer
	6. If you don't use the device for a long time, unplug and pour water out
Ø	7. Never use stearned water or very cold water.
0	8. Never touch water level sensor and avoid product hitting other objects
\oslash	Never put your hand above the ceramic disc when product is working, as this could cause pain and damage the machine
•	10. Never wrap the adapter with a cloth or paper, etc. Otherwise, it cannot dissipate hear normally and may cause deformation and burn the membrane from a short circuit. Never touch the adapter with wet hands.
\oslash	11. Do not use other liquids except for water & drops of essential or fragrance oils
Ø	 Do not aim the device at walls, ceilings, furniture surfaces as excess moisture could cause water damage.
•	 Do not take this unit apart exposing electrical parts. Call customer service for assistance and guarantee information.
	14. Never place on loose fabric that can block air flow and prevent the unit



We will be happy to assist you with any questions. Please contact our Customer Service Department at 1-888-548-0040. All calls are returned within 24 hours.



© 2018 GREENAIR INC. CLEVELAND, OH 44130 MADE IN CHINA www.newgreenair.com

LIMITED ONE YEAR GUARANTEE

U

Purchase of this diffuser includes a One Year Limited Guarantee that covers manufacturing defects. It excludes normal wear and tear, damage caused by improper use, oil damage to the outside of the diffuser or oil damage to any other personal materials that the oil may come into contact with.

If you believe your unit is defective or malfunctioning, please contact us at 888-548-0040.

Note that customers are responsible for return shipping costs if seeking replacement, even when covered by a guarantee. Manufacturer reserves sole discretion to determine whether replacement is needed. All diffusers sent to manufacturer for inspection must be clean and free of any oil residue or it will be returned without inspection.

THIS GUARANTEE IS EXCLUSIVE OF ALL OTHER GUARANTEES OFFERED BY THE MANUFACTURER, EXPRESSED OR IMPLIED, ALL OF WHICH ARE EXPRESSLY DISCLAIMED.